



Techniques to Fingerprint Construction Materials--R06B XRF and FTIR Spectroscopy

Committee on Materials and Pavements Cincinnati, OH August 9, 2018







AMERICAN ASSOCIATION OF STATE HIGHWAY AND TRANSPORTATION OFFICIALS



Techniques to Fingerprint Construction Materials (R06B)

Challenge

 Verify materials without sampling delays

Solution

- Technologies to verify specific construction materials in real time
- Technologies that can be used at the project site to determine specification compliance







Potential Benefits

- Rapid testing on site or in the lab
- Reduce testing time and cost
- Minimize noncompliance risk





R06B Technologies

X-Ray Fluorescence Spectroscopy (XRF)

- Rapid elemental analysis of materials
- Specific application developed in R06B testing traffic paints for Ti content





XRF Advantages and Limitations

Advantages

- Pre-calibrated for wide range of elements
- Automatic reading—no analysis
- 1-3-minute testing time
- Little or no sample prep required
- No maintenance required
- Numerous applications

Limitations


- Requires user certification
- Upper and lower limits—different calibrations needed for trace metals vs. ores





Fourier Transform Infrared (FTIR)

- Identifies compounds
- Simple testing process
- Analysis more difficult than XRF







R06B—Maine

XRF

- Chlorides in bridge deck cores
- Titanium in traffic paint
- REOB in PG Binder
- SS Rebar
- Galvanized coating thickness
- Glass Beads lead, arsenic
- Presence of RAS in HMA?

FTIR

- Polymer in PG Binder
- Library of all Binders
- Lime in HMA





R06B—Maine



Quantitative

Qualitative



Chloride Content – Bridge Deck Cores

- Current method: AASHTO T 260 (Gran Plot Method)
 - Requires nitric acid and silver nitrate
 - Numerous steps
 - 10 tests/day
- XRF method
 - No chemicals
 - 25+ tests/day
 - Less training required





Chloride Content – XRF method









Chloride Content – Bridge Deck Cores

Split-sample comparison


- Evaluated numerous binding agents for pelletized samples,
 XRF settings, direct measurement of concrete
- Selected the settings that provided the best correlation on a limited amount of measurements vs. titration values
- Expanded population of comparisons
- In-progress statistical validation

ltem	Levels	Details
Analysis Mode	3	AllGeo and Two Mining Modes
Time Breakdown	2	5/5/5/45 & 15/15/15/15
Binding Agent	6	None and 5 recommended agents
Binding %	2	5% & 10%
Replicates	3	Three measurements on each pellet




Surface Testing of Core Slices

а




Top, bottom, edge of slice Average of all readings v. Titration $R^2 \approx 0.91$

- Exposed aggregate a problem
- Higher variability



Pulverized specimens



SHRP2 SOLUTIONS | 13

Chloride Content – Bridge Deck Cores

- Conclusions from study
 - Pellets of pulverized material superior to surface readings of slices
 - No binding agent required
 - In process of:
 - testing lab-prepared reference samples
 - validating correlation with independent split-sample comparisons



Stainless steel rebar



El	%	+/- 2σ
V	0.110	0.010
Cr	23.490	0.073
Mn	1.818	0.045
Fe	70.056	0.093
Со	0.123	0.045
Ni	3.758	0.044
Cu	0.347	0.014
Zr	0.004	0.001
Nb	0.018	0.001
Мо	0.253	0.004
W	0.017	0.005
Pb	0.007	0.002

SHRP2SOLUTIONS | 15

R06B—Tennessee



XRF

- Silica and Calcium Carbonate in Limestone
- Titanium in Thermoplastic
- Glass Beads lead, arsenic
- REOB in Binder?
- Galvanized coating thickness?

FTIR

- Polymer in PG Binder
- Library of all Binders
- PPA in Binder





Heavy Metals in Glass Beads

- Current Practice:
 - Tennessee requires every lot to be tested with EPA tests 3052, 6010B, or 6010C.
- Future Method:
 - Perform XRF testing on every lot. Allow manufacturer to Certify lots to Federal Aid Standard.





Silica in Limestone

- Currently tested by standard-less program on WDXRF in Lab.
- Handheld can perform same testing but still requires a lot of sample prep to be accurate.





Titanium in Thermoplastic


- Current Practice:
 - Tennessee currently accepts thermoplastic on certification.
- Future Practice:
 - The handheld can perform verification testing in the field/lab on Thermoplastic.
 - There may be some issues with some fillers in the Thermoplastic.





Future for this Product in TN

- Looking into other materials
 - Following Maine and using XRF as a rapid test for Chloride Content of Bridge Decks.
 - Using the XRF and FTIR to detect REOB's and PPA's in our Binders.
 - Using the FTIR to verify Qualified Products List materials, such as Texture Coating and Additives for Asphalt and Concrete.





What's Next for R06B



The Future

- Webinar August 22, 2018
 - <u>https://collaboration.fhwa.dot.gov/dot/fhwa/WC/Lists/Semi</u> <u>nars/DispForm.aspx?ID=1706</u>
- Peer Exchange September 26-27, 2018
 - <u>https://fs6.formsite.com/Mrussell/form204/index.html</u>
- Regional User Producer Group Meetings?
- Others?



For More Information on R06B

Contacts

Kate Kurgan AASHTO Product Lead kkurgan@aashto.org

Steve Cooper FHWA Product Lead stephen.j.cooper@dot.gov

Maria Chrysochoou

Subject Matter Expert maria.chrysochoou@uconn.edu

Terry Arnold Technical Expert terry.Arnold@dot.gov

Additional Resources:

GoSHRP2 Website:	fhwa.dot.gov/GoSHRP2
AASHTO SHRP2 Website:	http://shrp2.transportation.org
R06B Product Page	Coming soon

